

UC500 Series

User Guide

Safety Precautions

Milesight will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.

- ❖ The device must not be remodeled in any way.
- ❖ Do not place the device close to objects with naked flames.
- ❖ Do not place the device where the temperature is below/above the operating range.
- ❖ Make sure electronic components do not drop out of the enclosure while opening.
- ❖ When installing the battery, please install it accurately, and do not install the reverse or wrong model.
- ❖ The device must never be subjected to shocks or impacts.


Declaration of Conformity

UC500 series is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



Copyright © 2011-2021 Milesight. All rights reserved.

All information in this guide is protected by copyright law. Whereby, no organization or individual shall copy or reproduce the whole or part of this user guide by any means without written authorization from Xiamen Milesight IoT Co., Ltd.



For assistance, please contact
Milesight technical support:
Email: iot.support@milesight.com
Tel: 86-592-5085280
Fax: 86-592-5023065
Address: 4/F, No.63-2 Wanghai Road,
2nd Software Park, Xiamen, China

Revision History

Date	Doc Version	Description
Jan. 20, 2021	V 1.0	Initial version

Contents

1. Product Introduction.....	4
1.1 Overview.....	4
1.2 Features.....	4
2. Hardware Introduction.....	4
2.1 Packing List.....	4
2.2 Hardware Overview.....	5
2.3 Internal Interfaces.....	6
2.4 Dimensions(mm).....	7
3. Hardware Installation.....	7
3.1 Hardware Switch.....	7
3.2 UC500 Installation.....	8
4. Operation Guide.....	9
4.1 Log in the ToolBox.....	9
4.1.1 NFC Configuration.....	9
4.1.2 USB Configuration.....	10
4.2 LoRaWAN Settings.....	12
4.3 Interface Settings.....	14
4.3.1 RS485 Settings.....	15
4.3.2 RS232 Settings.....	18
4.3.3 GPIO Settings.....	18
4.3.4 AI Settings.....	20
4.4 Maintenance.....	22
4.4.1 Upgrade.....	22
4.4.2 Backup.....	23
4.4.3 Reset to Factory Default.....	24
5. Milesight IoT Cloud Management.....	25
5.1 Add a Milesight Gateway.....	25
5.2 Add UC500 to Milesight IoT Cloud.....	26
6. Device Payload.....	27

1. Product Introduction

1.1 Overview

UC500 series is a LoRaWAN® controller used for data acquisition from multiple sensors. It contains different I/O interfaces such as analog inputs, digital inputs, digital outputs, serial ports and so on, which simplify the deployment and replacement of LoRaWAN® networks.

UC500 series can be easily and quickly configured by NFC or wired USB port. For outdoor applications, it provides solar or built-in battery power supply and is equipped with IP67-rated enclosure and M12 connectors to protect itself from water and dust in harsh environments.

1.2 Features

- Easy to connect with multiple wired sensors through GPIO/AI/RS232/RS485 interfaces
- Long transmission distance up to 11km with line of sight
- Waterproof design including IP67 case and M12 connectors
- Solar powered and built-in battery optional
- Quick wireless configuration via NFC
- Compliant with standard LoRaWAN® gateways and network servers
- Quick and easy management with Milesight IoT Cloud solution

2. Hardware Introduction


2.1 Packing List





1 × U50x Device




2 × Data Cables



1 × Mounting

Wall Mounting
Bracket
Kits1 × Warranty
Card

1 × Quick Guide



1 × DC Power Cable

(UC501 only)



1 × Solar Panel Kit



2 × Hose Clamps

(Optional)



If any of the above items is missing or damaged, please contact your sales Representative.

2.2 Hardware Overview




UC501

UC502


Data Interface 1:

Pin	Description	
1	5V/9V/12V(Switchable)	
2	3.3V	
3	GND	
4	GPIO1	
5	GPIO2	
6	RS232/RS485(Switchable)	
7		
8	Reserved	
Pin	RS232	RS485
6	TXD	A
7	RXD	B





Data Interface 2:

Pin	Description
1	5V/9V/12V(Switchable)
2	3.3V
3	GND
4	Analog Input 1
5	Analog Input 2
6	Reserved



Power Interface (UC501):

Pin	Description
1	VCC(5-24V)
2	GND

**2.3 Internal Interfaces****DIP Switch:**


Interface	DIP Switch
Power Output	12V: 1 on 2 off 3 off 9V: 1 off 2 on 3 off 5V: 1 off 2 off 3 on
Analog Input	4-20mA ADC: 1 off 2 on 3 off 0-10V ADC: 1 on 2 off 3 off
RS485	Add 120 Ω resistor between A and B: 1 on 2 off 3 off Add 1k Ω pull-up resistor on A: 1 off 2 on 3 off Add 1k Ω pull-down resistor on B: 1 off 2 off 3 on

Note:

- 1) Analog inputs are set to 4-20mA by default, power outputs are set to 12V by default.
- 2) Power output on interface 1 is used for powering serial port devices, power output on interface 2 is used for powering analog devices.

Power Button:


Function	Action	LED Indication
Turn On	Press and hold the button for more than 3s.	Off → On
Turn Off	Press and hold the button for more than 3s.	On → Off
Reset	Press and hold the button for more than 10s.	Blinks.
Check On/Off Status	Quickly press the power button.	Light On: Device is on.
		Light Off: Device is off.

2.4 Dimensions(mm)**3. Hardware Installation****3.1 Hardware Switch**

When using the analog input or power output of UC500 series, please follow the steps to switch the working mode of hardware interface:

1. Remove the screw caps and take off the roof cover.
2. Change DIP switches that are related analog inputs and power outputs as shown in [Section 2.3](#).
3. Put back the roof cover and screw the screws.

Note: Please turn off the device before changing DIP switches.




3.2 UC500 Installation

Wall Mounting

Make sure you have wall mounting bracket, bracket mounting screws, wall plugs, wall mounting screws and other required tools.

Steps:


1. Mount the enclosure to the mounting bracket with the bracket mounting screws.



2. Align the mounting bracket horizontally to the desired position on the wall, use a marker pen to mark four mounting holes on the wall, and then remove the mounting bracket from the wall.

Note: The connecting lines of adjacent points are at right angles.

3. Drill the four holes by using your drill with a 6 mm drill bit on the positions you marked previously on the wall.
4. Insert four wall plugs into the holes respectively.
5. Mount the mounting bracket horizontally to the wall by fixing the wall mounting screws into the wall plugs.




Pole Mounting

Make sure you have wall mounting bracket, bracket mounting screws, hose clamp and other required tools.

Steps:


1. Mount the enclosure to the mounting bracket with the bracket mounting screws.



2. Loosen the hose clamp by turning the locking mechanism counter-clockwise.



3. Straighten out the hose clamp and slide it through the rectangular holes in the mounting bracket, wrap the hose clamp around the pole.
4. Use a screwdriver to tighten the locking mechanism by turning it clockwise.



4. Operation Guide

4.1 Log in the ToolBox

UC500 series can be monitored and configured via ToolBox APP or ToolBox software. Please select one of them to complete configuration.

4.1.1 NFC Configuration

Preparation:

- Smartphone (NFC supported)
- Milesight ToolBox APP: V1.3.9 and above


Steps:

1. Download and install from Google Play or Apple Store.
2. Enable NFC on the smartphone and open "Milesight ToolBox" APP.
3. Attach the smartphone with NFC area to the device to read basic information.



4. Basic information and settings of devices will be shown on ToolBox if it's recognized

successfully. You can turn on/off the device by tapping the button on the Device Status. In order to protect the security of devices, password validation is required when configuring via unused phone . Default password is **123456**.



5. Tap "Read" button to check current status of device.
6. Tap "Write" button to write all your settings to the device.

Note:

- 1) Ensure the location of smartphone NFC area and it's recommended to take off phone case.
- 2) If the smartphone fails to read/write configurations via NFC, keep the phone away and back to try again.
- 3) UC500 series can also be configured by dedicated NFC reader, which can be purchased from Milesight IoT.


4.1.2 USB Configuration

Preparation:


- Type-C USB cable
- PC (Windows 10 is recommended)
- ToolBox: V6.35 and above

Steps:

1. Download ToolBox from [Milesight IoT website](#).
2. Open the case of UC500 and connect the UC500 to computer via type-C port.



3. Open the ToolBox and select type as "General", then click password to log in ToolBox.
(Default password: **123456**)



4. After logging in the ToolBox, you can click "Power On" or "Power Off" to turn on/off device and change other settings.

A screenshot of the Milesight IoT web interface. The sidebar on the left includes "Status", "General", and "LoRaWAN Settings". The main area shows "Status >" and a "Power On" button. Below it, detailed device information is listed:

Model:	UC501-915
Serial Number:	6412A4304414
Firmware Version:	01.01
Hardware Version:	2.1
Device Status:	Off
Join Status:	-
RSSI/SNR:	-
Battery:	-
Channel Mask:	-
Uplink Frame-counter:	-
Downlink Frame-counter:	-

4.2 LoRaWAN Settings

LoRaWAN settings is used for configuring the transmission parameters in LoRaWAN® network.

Step 1: Go to “**LoRaWAN -> Basic**” of ToolBox software or “**Setting->LoRaWAN Settings**” for ToolBox APP to configure join type, App EUI, App Key and other information. You can also keep all settings by default.

Device EUI	24E124412A430441
App EUI	24E124C0002A0001
Application Port	85
Working Mode:	Class A
Join Type	OTAA
Application Key	*****
Spread Factor	(?) SF10-DR2
Confirmed Mode	(?) <input type="checkbox"/>
Rejoin Mode	(?) <input checked="" type="checkbox"/>
Set the number of packets sent	32
ADR Mode	(?) <input checked="" type="checkbox"/>
TXPower	TXP0-22 dBm

Parameters	Description
Device EUI	Unique ID of the device which can also be found on the label.
App EUI	Default App EUI is 24E124C0002A001.
Application Port	The port used for sending and receiving data, default port is 85. Note: RS232 data will be transmitted via another port.
Working Mode	UC501: Class A and Class C are available; UC502: Class A.
Join Type	OTAA and ABP mode are available.
Application Key	Appkey for OTAA mode, default is 5572404C696E6B4C6F52613230313823.
Device Address	DevAddr for ABP mode, default is the 5 th to 12 th digits of SN.
Network Session Key	Nwkskey for ABP mode, default is 5572404C696E6B4C6F52613230313823.
Application Session Key	Appskey for ABP mode, default is 5572404C696E6B4C6F52613230313823.
Spread Factor	If ADR is disabled, the device will send data via this spread factor.
Confirmed Mode	If the device does not receive ACK packet from network server, it will resend data 3 times at most.
Rejoin Mode	Reporting interval ≤ 30 mins: device will send specific mounts of LoRaMAC

	packets to check connection status every 30 mins; If no reply after specific packets, the device will re-join.
	Reporting interval > 30 mins: device will send specific amounts of LoRaMAC packets every to check connection status every reporting interval; If no reply after specific packets, the device will re-join.
ADR Mode	Allow network server to adjust datarate of the device.
Tx Power	Based on LoRaWAN® regional parameter document.

Note:

- 1) Please contact sales for device EUI list if there are many units.
- 2) Please contact sales if you need random App keys before purchase.
- 3) Select OTAA mode if you use Milesight IoT cloud to manage devices.
- 4) Only OTAA mode supports rejoin mode.

Step 2: Go to “**LoRaWAN -> Channel**” of ToolBox software or “**Setting->LoRaWAN Settings**” for ToolBox APP to select supported frequency and select channels to send uplinks. Make sure the channels match the LoRaWAN® gateway.

Index	Frequency/MHz	Max Datarate	Min Datarate
0	868.1	5-SF7BW125	0-SF12BW125
1	868.3	5-SF7BW125	0-SF12BW125
2	868.5	5-SF7BW125	0-SF12BW125
3	0	5-SF7BW125	0-SF12BW125
4	0	5-SF7BW125	0-SF12BW125
5	0	5-SF7BW125	0-SF12BW125
6	0	5-SF7BW125	0-SF12BW125

If frequency is one of CN470/AU915/US915, you can enter the index of the channel that you want to enable in the input box, making them separated by commas.

Examples:

- 1,40: Enabling Channel 1 and Channel 40
- 1-40: Enabling Channel 1 to Channel 40
- 1-40, 60: Enabling Channel 1 to Channel 40 and Channel 60
- All: Enabling all channels
- Null: Indicates that all channels are disabled

Support Frequency : AU915 ▼

Enabled Channel Index: ? 0-71

Channel Index	Frequency/MHz	Channel Spacing/MHz	BW/kHz
0 - 15	915.2 - 918.2	0.2	125
16 - 31	918.4 - 921.4	0.2	125
32 - 47	921.6 - 924.6	0.2	125
48 - 63	924.8 - 927.8	0.2	125
64 - 71	915.9 - 927.1	1.6	500

Note:

For -868M model, default frequency is EU868;

For -915M model, default frequency is AU915.

4.3 Interface Settings

UC500 series support data collection by multiple interfaces including GPIOs, analog inputs and serial ports. Besides, it can also power the terminal devices by power output interfaces. Basic settings are as follows:

Step 1: Go to “**General->Basic**” of ToolBox software or “**Setting->General Settings**” page to change the reporting interval.

Reporting Interval	600 s
The device returns to the power supply state	Last working status ▼
Interface 1 (Pin2) 3V3 Output	<input type="checkbox"/>
Interface 2 (Pin2) 3V3 Output	<input type="checkbox"/>
Change Password	<input type="checkbox"/>

Parameters	Description
Reporting Interval	Reporting interval of transmitting data to network server.Default: 600s Note: RS232 transmission will not follow the reporting interval.
The device returns to the power supply state	If the device loses power and return to power supply, the device will be on or off according to this parameter.

Interface 1/2 3V3 Output	Enable 3.3V power output. After enabled, the power output will supply power continuously .
Change Password	Change the password for ToolBox APP or software to read/write this device.

Step 2: Go to corresponding pages to change GPIO, analog input or serial port settings as following chapters.

4.3.1 RS485 Settings

Step 1: Connect RS485 device to RS485 port on interface 1. If you need UC500 to power this device, please connect the power cable to 5V/9V/12V power output on interface 1.

Step 2: Go to “General -> Serial” of ToolBox software or “Setting->Serial Setting” to enable RS485 and configure serial port settings. Serial port settings should the **same** as RS485 terminal devices.

Enable	<input checked="" type="checkbox"/>
Interface Type	RS485 (Modbus Master) <input type="button" value="▼"/>
Interface 1 (Pin1) 5/9/12V Output	<input type="checkbox"/>
Baud Rate	9600 <input type="button" value="▼"/>
Data Bit	8 bits <input type="button" value="▼"/>
Stop Bit	1 bits <input type="button" value="▼"/>
Parity	None <input type="button" value="▼"/>
Execution Interval	50 <input type="text"/> ms
Max Resp Time	500 <input type="text"/> ms
Max Retry Times	3 <input type="text"/>
Modbus RS485 bridge LoRaWAN	 <input type="checkbox"/>

Parameters	Description
Interface 1/(Pin 1) 5V/9V/12V	Enable 5V/9V/12V power output of interface 1 to supply power to RS485 terminal devices. It's 12V by default and you can change DIP switches to change voltage.
Power Output Time Before Collect	UC500 will power the RS485 terminal devices for a period of time before collecting data for terminal device initialization.
Baud Rate	300/1200/2400/4800/9600/19200/38400/57600/115200 are available.

Data Bit	8 bit is available.
Stop Bit	1 bit/2 bit are available.
Parity	None, Odd and Even are available.
Execution Interval	The execution interval between each Modbus command.
Max Resp Time	The maximum response time that the UC500 waits for the reply to the command. If it does not get a response after the max response time, it is determined that the command has timed out.
Max Retry Time	Set the maximum retry times after device fails to read data from RS485 terminal devices.
Modbus RS485 bridge LoRaWAN	If this mode is enabled, UC500 will transparent Modbus RTU commands from network server to RS485 terminal devices and send Modbus reply originally back to network server. Port: Select from 2-84, 86-223.

Note: When you use power output to power RS485 Modbus slave devices, it only supplies power when reporting interval is coming. It's suggested to power slave devices with external power during the test.

Step 3: Click  to add Modbus channels, then save configurations.

Channel Settings

Channel ID	Name	Slave ID	Address	Quantity	Type	Sign	Value	Fetch
1	Temperature	1	0	1	Input Register(INT16)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
 								 Up to 16 channels

Parameters	Description
Channel ID	Select the channel ID you want to configure, 16 channels selectable.
Name	Customize the name to identify every Modbus channel.
Slave ID	Set Modbus slave ID of terminal device.
Address	The starting address for reading.
Quantity	Set read how many digits from starting address. It fixes to 1.
Type	Select data type of Modbus channels.
Sign	The tick indicates that the value has a plus or minus sign.

Example: If you configure as following picture, UC500 will send Modbus read command to terminal device regularly: 01 03 00 00 00 01 84 0A

Channel ID	Name	Slave ID	Address	Quantity	Type	Sign	Decimal Place	Value
1	Temperature	1	0	1	Holding Register(INT16)	<input type="checkbox"/>	0	
<input type="button" value="Fetch"/> <input type="button" value="X"/> <input type="button" value="+"/>								
<input type="button" value="Save"/> Up to 16 channels								

Step 4: For ToolBox software, click “Fetch” to check if UC500 can read correct data from terminal devices. You can also click “Fetch” on the top of list to fetch all channel data.

Channel ID	Name	Slave ID	Address	Quantity	Type	Sign	Value
1	1	1	16	1	Input Register(INT16)	<input type="checkbox"/>	564
2	2	2	12	1	Holding Register(INT16)	<input type="checkbox"/>	
3	1	1	17	1	Input Register(INT16)	<input type="checkbox"/>	

Note: Please do not click “Fetch” frequently since response time to reply is differ for every terminal device.

For ToolBox APP,

- Tap every Modbus channel, click “Collect” and attach smart phone to device to make device collect data.

← Temerature

* Name

Slave ID

Address

Quantity

Type

Sign

Value

- Click “Fetch” and attach smart phone to make APP read the data.

You can also tap “Collect All” and “Fetch All” to fetch all channel data.

4.3.2 RS232 Settings

Step 1: Connect RS232 device to RS232 port on interface 1. If you need UC500 to power this device, please connect the power cable to 5V/9V/12V power output on interface 1.

Step 2: Go to “**General -> Serial**” of ToolBox software or “**Setting->Serial Setting**” to enable RS232 and configure serial port settings. Serial port settings should be the **same** as RS232 terminal devices.

Enable	<input checked="" type="checkbox"/>
Interface Type	RS232
Interface 1 (Pin1) 5/9/12V Output	<input type="checkbox"/>
Baud Rate	9600
Data Bit	8 bits
Stop Bit	1 bits
Parity	None
Port	86

Parameters	Description
Interface 1/(Pin 1)	Enable 5V/9V/12V power output of interface 1 to supply power to RS232 terminal devices continuously . Only UC501 supports this feature.
5V/9V/12V	Note: Power output is 12V by default and you can change DIP switches to change voltage.
Baud Rate	300/1200/2400/4800/9600/19200/38400/57600/115200 are available.
Data Bit	8 bit is available.
Stop Bit	1 bit/2 bit are available.
Parity	None, Odd and Even are available.
Port	The port used for RS232 data transmission.

4.3.3 GPIO Settings

Step 1: Connect devices to GPIO ports on interface 1.

Step 2: Go to “**General -> GPIO**” of ToolBox software or “**Setting->GPIO Setting**” to enable GPIO port.

Interface Name	GPIO 1	
Enable	<input checked="" type="checkbox"/>	
Interface Type	Digital Input1	
Digital Input		Pull Down
Status	<input type="text"/> —	
		Fetch
Interface Name	GPIO 2	
Enable	<input checked="" type="checkbox"/>	
Interface Type	Digital Input2	
Digital Input		Pull Down
Status	<input type="text"/> —	
		Fetch
Save		

Step 3: Select GPIO type according to your requirements.

- **Digital Input:** detect high or low status of devices;
- **Digital Output:** Send voltage signal to trigger devices;
- **Counter:** pulse counter.

Digital Input:

Step 4: Select initial status of digital input. If pull up is selected, falling edge will be triggered; If pull down is selected, rising edge will be triggered.

Step 5: Click “Fetch” to check current status of digital input.

Interface Name	GPIO 1	
Enable	<input checked="" type="checkbox"/>	
Interface Type	Digital Input1	
Digital Input		Pull Down
Status	<input type="text"/> Low	
		Fetch

Digital Output:

Step 4: Click “Switch” to check if UC500 can trigger devices by digital output.

Step 5: Click “Fetch” to check current status of digital output.

Interface Name	GPIO 1
Enable	<input checked="" type="checkbox"/>
Interface Type	Digital Output1
Status	Low <input checked="" type="checkbox"/> Fetch <input type="button" value="Switch"/>

Pulse Counter:

Step 4: Select initial status of digital input. If pull up is selected, falling edge will be triggered and increase 1; if pull down is selected, rising edge will be triggered and increase 1.

Interface Name	GPIO 1
Enable	<input checked="" type="checkbox"/>
Interface Type	Counter
Digital Input	<input type="button" value="?"/> Pull Down
Digital Filter	<input type="button" value="?"/> <input checked="" type="checkbox"/>
keep last value when power off	<input checked="" type="checkbox"/>
Counter values	0 <input type="button" value="Refresh"/> <input type="button" value="Start"/> <input type="button" value="Clear"/>

Parameters	Description
Digital Input	Initial status of counter. Pull Down: Increase 1 when detecting rising edge Pull Up/None: Increase 1 when detecting falling edge
Digital Filter	It's recommended to enable when pulse period is greater than 250us.
Keep last value when power off	Keep counted values when device powers off.

Step 5: Click "Start" or "Stop" to make the device start/stop counting.

Step 6: Check current count values by clicking "Refresh".

Step 7: Click "Clear" to make the device count from 0.

Note:

- 1) UC500 only starts counting when it detects 6 pulses from pulse devices;
- 2) UC500 will send non-changeable counting values if you do not click "Start".

4.3.4 AI Settings

Step 1: Connect analog device to analog input ports on interface 2. If you need UC500 to power the analog device, connect the power cable of device to 5V/9V/12V power output on interface 2.

Step 2: Go to "**General -> AI**" of ToolBox software or "**Setting->AI Setting**" to enable analog input.

Interface 2 (Pin1) 5/9/12V Output	<input checked="" type="checkbox"/>
Power Output Time Before Collect	<input type="text" value="0"/> ms
Interface Name	Analog Input 1
Enable	<input checked="" type="checkbox"/>
Analog Input Signal Type	<input type="text" value="4-20 mA"/>
Status	<input type="text"/> <button>Fetch</button>
Interface Name	Analog Input 2
Enable	<input checked="" type="checkbox"/>
Analog Input Signal Type	<input type="text" value="0-10 V"/>
Status	<input type="text"/> <button>Fetch</button>

Step 3: Select analog input type according to analog device type.

Note: Ensure [DIP switches](#) has changed before changing "Analog Input Signal Type" to 0-10V.

Step 4: Enable "Interface 2(Pin 1) 5V/9V/12V" and configure "Power Output Time Before Collect", UC500 will power the analog devices for a period of time before collecting data.

Interface 2 (Pin1) 5/9/12V Output	<input checked="" type="checkbox"/>
Power Output Time Before Collect	<input type="text" value="0"/> ms


Note: When you use power output to power analog devices, it only supplies power when reporting interval is coming. It's suggested to power slave devices with external power during the test.

Step 5: For ToolBox software, click "Fetch" to check if UC500 can read correct data from analog devices.

Interface Name	Analog Input 2
Enable	<input checked="" type="checkbox"/>
Analog Input Signal Type	<input type="text" value="0-10 V"/>
Status	<input type="text" value="0.00 V"/> <button>Fetch</button>

For ToolBox APP,

- Click “Collect” and attach smart phone to device to make device collect data.
- Click “Fetch” and attach smart phone to make APP read the data.



4.4 Maintenance

4.4.1 Upgrade

UC500 series support upgrade locally or over the air only via ToolBox software.

Model:	UC501-915
Firmware Version:	01.01
Hardware Version:	2.1
Domain:	Singapore Server
FOTA:	Up to date
Update Locally	<input type="file"/> Browse Upgrade

Upgrade Locally:

Step 1: Click “Browse” to import firmware from your computer.

Step 2: Click “Upgrade” to start the upgrade.

Upgrade Over the Air:

Step 1: Select the upgraded server according to your region and make sure your computer can access the Internet.

Step 2: Click “Up to date” to search for latest firmware of devices. If your firmware is latest version, ToolBox will prompt “Your device is up to date”.

Note: Any operation on ToolBox is not allowed during upgrading, otherwise the upgrading will be

interrupted, or even the device will break down.

4.4.2 Backup


UC500 devices support configuration backup for easy and quick device configuration in bulk.

Backup is allowed only for devices with the same model and LoRa frequency band. Please select one of following methods to backup device:

Via ToolBox Software

Step 1: Go to “Maintenance->Backup and Reset”, click “Export” to save current configuration as json format backup file.


Step 2: Click “Browse” to select backup file, then click “Import” to import the configurations.



Via ToolBox APP

Step 1: Go to “Template” page on the APP and save current settings as a template. You can also edit the template file.

Step 2: Select one template file which saved in the smartphone and click “Write”, then attach to another device to write configuration.




4.4.3 Reset to Factory Default


Please select one of following methods to reset device:

Via Hardware: Open the case of UC500 and hold on power button more than 10s.

Via ToolBox Software: Go to “Maintenance->Backup and Reset” to click “Reset”.



Via ToolBox APP: Go to “Device->Reset” to click “Reset”, then attach smart phone with NFC area to UC500 to complete reset.



5. Milesight IoT Cloud Management

UC500 series can be managed by Milesight IoT Cloud platform. Milesight IoT cloud is a comprehensive platform that provides multiple services including device remote management and data visualization with the easiest operation procedures. Please register a Milesight IoT Cloud account before operating following steps.


5.1 Add a Milesight Gateway

Step 1: Enable “Milesight” type network server and “Milesight IoT Cloud” mode in gateway web GUI.

Note: Ensure gateway has accessed the Internet.

The image contains two screenshots of the Milesight IoT Cloud web interface. The top screenshot shows the 'General' tab of the 'Network Server' configuration page. It displays fields for 'Gateway EUI' (24E124FFxxxx), 'Gateway ID' (24E124FFxxxx), and 'Frequency-Sync' (Disabled). Below this is a 'Multi-Destination' table with one row, where the 'ID' column is highlighted with a red box. The bottom screenshot shows the 'General' tab of the 'Network Server' configuration page. It displays fields for 'Enable' (checked) and 'Milesight IoT Cloud' (checked). Other fields include 'NetID' (010203), 'Join Delay' (5 sec), 'RX1 Delay' (1 sec), 'Lease Time' (8760-0-0 hh-mm-ss), and 'Log Level' (info).

Step 2: Go to “My Devices” page and click “+New Devices” to add gateway to Milesight IoT Cloud via SN. Gateway will be added under “Gateways” menu.



Step 3: Check if gateway is online in Milesight IoT Cloud.

Status	Name	Associated Devices (Joined / Not Joined / Failed)	Last Updated
	UG Gateway 6222A3243835	0 / 0 / 0 Detail	a few seconds ago

5.2 Add UC500 to Milesight IoT Cloud

Step 1: Go to “My Devices” page and click “+New Devices”. Fill in the SN of UC500 and select associated gateway.

* SN:	6412A5196409
* Name:	UC501
* Associated Gateway:	UG Gateway
* Device EUI:	24e124412A519640
* Application Key:	5572404c696e6b4c6f52613230313823

Step 2: Default working mode of UC500 devices is Class A. If you need to change the mode of UC501 to Class C, click and go to “Basic Settings” to change mode to Class C.

Devices / UC501 / Basic Settings

Basic Settings **Interface Settings** **Maintenance** **Log** **Refresh** **Share**

* Name:	UC501
* Application Key:	5572404c696e6b4c6f52613230313823
LoRaWAN Class <small>(i)</small> :	classC
Description:	
* Reporting Interval <small>(i)</small> :	20 min

Step 3: After UC500 is online in Milesight IoT Cloud, click  and go to "Interface Settings" to select used interfaces and customize the name, sign and formulas.

Note: Modbus channel settings should be the same as the configuration in ToolBox.

Milesight IoT Cloud

Devices / UC501 / Interface Settings

Basic Settings **Interface Settings** **Maintenance** **Log** **Refresh** **Share**

Enable <small>(i)</small>	Name	Type	Custom Name			Current Value	Alarm Threshold		
<input checked="" type="checkbox"/>	GPIO_1	Digital Input	Low	Low	High	High	= <input type="button" value="Disable"/>		
<input checked="" type="checkbox"/>	GPIO_2	Digital Output	Low	Low	High	High	= <input type="button" value="Disable"/>		
Enable <small>(i)</small>	Name	Type	Osh	Osl	Unit	Current Value	Alarm Threshold		
<input type="checkbox"/>	AI_1	4 ~ 20mA	<input type="text" value="20"/>	<input type="text" value="4"/>	<input type="text" value="mA"/>	Ccy: - mA Min: - mA Max: - mA Avg: - mA	<input type="button" value="≤"/> <input type="button" value="≥"/>		
<input type="checkbox"/>	AI_2	4 ~ 20mA	<input type="text" value="20"/>	<input type="text" value="4"/>	<input type="text" value="mA"/>	Ccy: - mA Min: - mA Max: - mA Avg: - mA	<input type="button" value="≤"/> <input type="button" value="≥"/>		
Channel ID	Channel Name	Type	Sign	Raw Data <small>(i)</small>	Formula <small>(i)</small>	Value	Unit	Alarm Threshold	Operation
1	Temperature		<input type="checkbox"/>	HEX:- DEC:-	<input type="text"/>	-	<input type="text"/>	<input type="button" value="≤"/> <input type="button" value="≥"/>	<input type="button" value="Delete"/>

6. Device Payload

UC500 Series use the standard Milesight IoT payload format based on IPSO. Please refer to the **UC500 Series Communication Protocol**, for decoders of Milesight IoT products please click [here](#).

-END-