

What's in the box?

In addition to this guide, the package includes the following items:




DL-110-E or DL-110-E-W or DL-120-E or DL-120-E-W



IP67 RJ45



IP67 Power Plug



Quick Start

DL-110-E/DL-120-E Getting Started/User Manual

- DL-110-E/DL-120-E User Manual

<http://ftp.icpdas.com.tw/pub/cd/IIoT/DL-100/DL-100-E/Document/>

- Utility

<http://ftp.icpdas.com.tw/pub/cd/IIoT/utility>

- DL-110-E/DL-120-E Website

http://www.icpdas.com/root/product/solutions/remote_io/rs-485/dl_series/dl-110-e.html



If there is any other question, please feel free to contact us.

Email: service@icpdas.com

產品內容

除了本『快速安裝指南』外，此產品內容還包括以下這些配件：




DL-110-E 或 DL-110-E-W 或 DL-120-E 或 DL-120-E-W



IP67 RJ45



IP67 電源插頭



快速上手指南

DL-110-E/DL-120-E 快速入門指南/使用手冊

- DL-110-E/DL-120-E 使用手冊

<http://ftp.icpdas.com.tw/pub/cd/IloT/DL-100/DL-100-E/Document/>

- Utility

<http://ftp.icpdas.com.tw/pub/cd/IloT/utility>

- DL-110-E/DL-120-E 網站

http://www.icpdas.com/root/product/solutions/remote_io/rs-485/dl_series/dl-110-e.html



如果有任何問題，歡迎與我們連繫。

客服信箱：service@icpdas.com